



Elektroninen lämpötilasäädin / Electronic temperature controller

- 1) Valon kytkeminen. (laitteen takana valokytkin)
- 2) Lumihiihtäminen /sulatus
- 3) Asetus/SET-näppäin
- 4) Lämpötilan säätö (nuolet ylös/alas)
- 5) Virtakytkin

- 1) Light switch
- 2) Snowflake/defrost-button
- 3) SET-button
- 4) Temperature setting up/down
- 5) Power switch



Kuva 5 / Picture 5

Kaapin lämpötilaa säädetään:

1. Paina "SET" näppäintä, kunnes "°C" alkaa vilkkua.
2. Valitse haluttu lämpötila nuolinäppäimistä painamalla.
3. Valittu uusi arvo jää muistiin automaattisesti
4. Lämpötilansäädin palautuu automaattisesti näyttämään kaapin sisälämpötilaa.
5. Koneiston kestää jonkun aikaa saavuttaa uusi asetettu lämpötila. Uusi asetettu lämpötila ilmestyy näytölle kun se on saavutettu. Automaattisen sulatuksen aikana näytössä vilkkuu lumihiihtäjä (kts. Kuva 5, näppäin 2). Tämä on automaattinen toiminto, eikä vaadi käyttäjältä toimenpiteitä.

Temperature can be changed by following way:

1. Press "SET" button until "°C" starts to blink.
2. Choose the desired temperature by pressing up or down -button.
3. New temperature is saved automatically.
4. The display returns automatically showing cooler inner temperature.
5. It takes some time to reach the desired temperature. New temperature appears on the panel when it is reached. During the automatic defrost, snowflake icon appears on the screen. This is a fully automatic operation, and does not require any action from the user.