



# Wireless Neckband Earphones PBT114 User Manual





## Using the Earbuds

## **Charging the Earbuds**

Attach the small connector of the supplied micro-USB cable to the USB charging port on the side of the earbuds. Attach the large connector to the USB port on a computer, USB charging device, or a **5V USB adapter** (not included) and plug into a wall socket.

The LED indicator will turn **RED** while charging and turn off when fully charged.

When low on power, a voice will be heard, indicating that the earbuds should be charged.

# Pairing the Earbuds

- Long press the [ ] button. A tone will be heard and the LED indicator will flash RED and BLUE.
- Set your mobile device to search for Bluetooth devices. When it appears, select PBT114 from the list of found devices.
- 3. Once successfully paired, a tone will be heard and the LED indicator will flash BLUE.

When powered ON, the earbuds will automatically reconnect to the device it was most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled.

# Before You Begin...


## In the Box


- PBT114 Wireless Neckband Earphones
- Micro-USB Charging Cable
- Extra Silicone Ear Tips

## **Location of Controls**

(Control Piece - Front)

- 1. [ ] Button
- 2. [ ] Button
- 3. [ + ] Button
- 4. LED Indicator (Side)
- 5. USB Charging Port (Back)
- 6. Microphone





# Using the Earbuds (cont'd)

## Powering the Earbuds ON/OFF

- Long press the [ ] button to power the earbuds ON/OFF.
- If inactive for 8 minutes and not connected to Bluetooth, the earbuds will automatically turn OFF.

## **Playing Music**

To enjoy music wirelessly on your earbuds, make sure you are paired to a Bluetooth-enabled device. For more on pairing the earbuds to your device, please consult the **Pairing the Earbuds** section of this user manual. Once paired, you can control media playback and volume adjustment with the controls on your paired device.

- Quick press the [ ] button to *play/pause media playback*.
- Quick press the [ ] and [ + ] buttons to *skip to previous and next tracks*.
- Long press the [ ] and [ + ] buttons to **decrease and increase volume**. A tone will be heard if trying to increase the volume past the maximum level.

## **Phone Calls**

- Quick press the [ ] button to answer an incoming phone call or end an existing one.
- Long press the [ ] button to **send an incoming phone call to your voicemail**.
- Double quick press the [ ] button to *redial the last number called on your phone*.

## Legal Information

## READ CAREFULLY AND SAVE FOR FUTURE REFERENCE

#### **FCC Information**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **Radio Frequency Exposure Information**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## Warranty Information

This product as supplied and distributed new by AIT, Inc. ("AIT") to the original consumer purchaser is warranted by AIT against defects in material and workmanship for a period of one year from your date of purchase ("Warranty"). In the unlikely event that this product is defective, or does not perform properly, you may within one year from your original date of purchase return it to the authorized service center for repair or exchange.

#### TO OBTAIN WARRANTY SERVICE:

- Go to our website portal to receive an SRO number.
- Provide proof of the date of purchase within the package (dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping, will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

AIT, Inc. Customer Service Dept. 36 c/o Southern Telecom 400 Kennedy Drive Sayreville NJ 08872

For further customer service:

Southern Telecom.com
Click on Product Support

IN NO EVENT WILL AIT, ITS MANUFACTURERS, DISTRIBUTORS OR PLR IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) RELATED TO THIS PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY.

# Legal Information (cont'd)

#### WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).



The crossed-out garbage bin symbol means that you must not dispose of this product together with unsorted household waste.

#### Rain/Moisture Warning

- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions, or wet conditions.
- Do not submerge in water.
- Do not open this product or attempt to repair the unit yourself should it not be working.



PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.

Polaroid, Polaroid & Pixel, Polaroid Color Spectrum, and Polaroid Classic Border Logo are trademarks of PLR, IP Holdings, LLC, used under license.

