



# **KOGAN 45W PD USB-C CHARGER**

KACHG45W1CA

# SAFETY & WARNINGS

- Before each use, inspect the unit for any external damage. Do not operate the charger if it appears to be damaged.
- Users who are under 8 years of age or individuals with reduced physical, mental, or sensory capabilities should only use the device under supervision.
- Ensure to use USB charging cables specifically designed for high charging currents of 3A. Using unsuitable charging cables may result in burnout or malfunctions.
- Keep the charger away from naked flames during operation.
- Avoid using the charger in high humidity environments, such as bathrooms, or in dusty areas.
- Allow the charger to adjust to its surroundings before use if it has been transported from a cold environment to a warm one. Moisture might have formed inside due to condensation.
- The unit should not be opened, as there are no user serviceable components.
- If the unit malfunctions or emits an unusual smell, cease use immediately and contact **help.Kogan.com** for support.

# SPECIFICATIONS

<b>Input:</b>	100-240V, 50/60Hz, 1.2A
<b>Output:</b>	45W Max
<b>PPS:</b>	3.3-11V/4.05A, 3.3-16V2.8A, 3.3-21V2.1A
<b>PDO:</b>	5V 3A/9V 3A/15V 3A/20V 2.25A

## Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up.

For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

**kogan.com**