



QUICK START

POLY ATA 402



poly.com/support/ata-402

 poly.com/support/ata-402

HP EU
HP Deutschland, GmbH, HQ-Technical Regulations
Schickardstr. 32, 71025 Boeblingen, Germany

HP Inc UK Ltd.
Regulatory Enquiries, Earley West,
300 Thames Valley Park Drive,
Reading, RG6 1PT, England




© 2023 Poly. All trademarks are the property of their respective owners.



1725-88162-001A 06/23

RMN: Poly ATA 402

CONTENTS



Poly ATA 402



Power Adapter



Ethernet Network Cable

YOU WILL NEED

- Touch-tone phone
- Active Internet connection
- Access to the Internet via an Ethernet port on your router or modem
- (Optional) Internet phone service subscription
- (Optional) To wall-mount the ATA 402 device, two 5 mm (3/16 in.) screws and anchors (not supplied)

LED



Off: No Power
Solid green: Powered on and working
Flashing green: Searching for a DHCP IP address
Flashing orange: Upgrading (Do not unplug power.)
Solid red: Not operational



Flashing green (fast blinking): Data activity on the LAN Ethernet port



Flashing green (fast blinking): Data activity on the PC Ethernet port



Off: Port service not available
Solid green: Phone ready (standby)
Flashing green: Phone in use

ATA system web interface

1. From a phone attached to the ATA device, dial *** to access the ATA config attendant.
2. Choose 1 to hear the IP address of the ATA device.
3. Enter the ATA device IP address in a local PC web browser.
4. When prompted, enter **admin** for the user name and **admin** for the password.

CABLING

