



QuickStartGuide


ARIRC600i
www.arinfiniteradio.com

Congratulations on purchasing your new Acoustic Research Wi-Fi Internet Radio.


Please follow these instructions to set up and start using the radio.

1 Unpack the unit

You should find the following items in the box:



Radio




Remote control*




AM loop antenna




Ethernet cable



User Manual



Quick Start
Guide (this
leaflet)



Setup
Information
Card

Additional requirements:

- Broadband Internet service
- Broadband (cable/DSL) modem, usually supplied by your Internet service provider
- An 802.11 b or g (Wi-Fi) wireless home network or Ethernet router/switch/hub with available LAN port

For Wi-Fi connections, you may also need:

- Your wireless network's SSID
- Your access password (for secure networks)

2 Setup your AR Infinite Radio accounts




To simplify setup on the radio please complete these steps:


- Find the Setup Information Card that contains your radio's MAC address number (MAC: 00-21-2A-XX-XX-XX) and activation PIN # (PIN: 0000). (This number is also found in the Device Info screen under the Settings menu in your radio or on the sticker located on the back of the radio.)
- Using any Internet-connected computer, go to **www.arinfiniteradio.com/setup** and follow the online instructions.
 - You will need to input your radio's MAC address and PIN # to associate your radio with your personal settings.

3 Optional: For use with a "Wired" connection

Use the supplied Ethernet cable if you do not have a wireless (Wi-Fi) access point.



4 Plug in and turn on the radio




Exit the DEMO mode after
turning on

Press and release preset **1**, then
SLEEP, then preset **6**.

5 Set up the radio



A. **NOTE:** When you turn on the radio for the first time, it will be in **"DEMO"** mode. To exit this mode, press and release preset **1**, then **SLEEP**, then preset **6** on top of the radio.

B. After exiting the DEMO mode, the radio displays the **Select Language** screen. Choose your preferred language.



C. The **Network Setup** screen displays connection options:


- Select **Wired** to connect using an Ethernet cable and proceed to step D.
- OR
- Select **Wireless**, then choose from setup options displayed:
 - Detect Networks** allows you to search for available networks, then choose your network.
 - Enter SSID** allows you to manually enter a known network name (SSID). See tips to the right.
 - If the network is secure, select security type and/or enter your password in the **Network Security** screen.




D. The radio should now connect to the Internet. If the radio does not connect refer to the troubleshooting section in your user manual.

After connecting to the Internet

- If you did not activate your Infinite Radio accounts, or if the radio cannot get your details from the Infinite Radio server, the radio may ask for your postal code. Input your code.
- If your radio has successfully connected to the Internet you will hear a welcome message.



Use the navigation controls to make choices and input information:



▲ – move highlight up
▼ – move highlight down
◀/▶ – move selection/navigate left
▶/▶ – move selection/navigate right
SELECT - confirm selected option or character

When inputting characters, press ▲ or ▼ to choose among uppercase, lowercase, numeric, or special characters.
To insert spaces or correct mistakes, press ▼ to display the Commands list and then press ◀◀ or ▶▶ (or ◀/▶) to choose the desired command.

About passphrase:


- This radio supports secured access points using the Wireless Equivalent Privacy (WEP) keys or Wi-Fi Protected Access (WPA and WPA2) standards.
- WEP keys are either 10 or 26 characters long (e.g. 6E78214A52). Note that some Wi-Fi routers support passphrase generation for WEP security. However, there is no industry standard for WEP passphrase generation and *this radio does not support WEP passphrases*.
- If you are using a WEP secured access point, enter the WEP key (HEX format) instead of the passphrase.

Learn more about your Internet Radio


Read the **user manual** for more information on the player's features, safety and warranty information, and answers to Frequently Asked Questions (FAQ's).

Need more help? Do not return this product to the store.
Visit **www.arinfiniteradio.com** to get the latest firmware updates and FAQ's.


Controls



Top/Front



Back



Remote control

RealAudio is a trademark or a registered trademark of RealNetworks, Inc.

Using the radio

General procedures

Turn on/off (standby) the radio	Press ON/STANDBY .
Choose an audio source	Press SOURCE to cycle through the audio sources (Internet Radio, MP3tunes, FM/AM Tuner, iPod, Internal Memory, USB Input or Aux-in).
Choose a preset radio station (Internet, FM, or AM mode)	On the remote control, press PRESET and then ▲ or ▼ to choose a preset station from the list and then press SELECT or ▶▶ .
Assign the current radio station to a preset	Press and hold a preset button (1–6).
Display the menu while listening	Press ⏠ .
Record the current AM/FM/Internet radio station	Press ○ . Press ○ again to stop recording.
Display the time	Press ⌚ .
Set the time	Press and hold ⌚ until the hour is highlighted. Press ◀◀ or ▶▶ (or ◀/▶) to choose hours, minutes or AM/PM (for 12-hour display mode). Press ▲ or ▼ to change the time. Press SELECT to set the time.

Listening to Internet radio

Choose an Internet radio station	Press SOURCE to choose Internet Radio. Press ▲ or ▼ to move up and down the menu options and press SELECT to navigate to the desired station.	<div>INTERNET RADIO My Genres My Favorites Music Talk</div>
Start playing the selected station	Press SELECT .	
Mark the current station as a favorite	Press ♥ or press ⏠ to display the options menu. Press ▼ to choose Add to Favorites and then press SELECT .	
Remove the current station from My Favorites	Press ⊗ .	

Listening to MP3tunes

Set up MP3tunes Locker	Refer to MP3tunes section of the user manual.
Play an audio file from MP3tunes Locker	Press SOURCE to choose MP3tunes. Press ◀◀ or ▶▶ (or ◀/▶) to exit or enter categories. Press ▲ or ▼ to highlight a file and press SELECT or ▶▶ to start playback.
Pause playback	Press ▶▶ . Press again to resume.
Skip to the next audio file	Press ▶▶ or ▶ .
Skip to the previous audio file	Press ◀◀ or ◀ within the first 3 seconds of the current file.

Listening to FM/AM radio

Tune in an FM/AM radio station	Press SOURCE to choose FM or AM radio. Press and hold ◀◀ or ▶▶ (or ◀/▶) until the radio beeps to auto-tune to the previous or next available station.
Step through the radio frequencies	Press ◀◀ or ▶▶ (or ◀/▶).

Playing recordings, iPod and audio files

Play a recording	Press SOURCE to choose Internal Memory. Press ▲ or ▼ to highlight a recording and press SELECT .
Connect iPod with the radio	Refer to iPod section of the user manual.
Play an audio file from a connected USB device or iPod	Press SOURCE to choose USB or iPod. Press ◀◀ or ▶▶ (or ◀/▶) to exit or enter folders. Press ▲ or ▼ to highlight a file and press SELECT or ▶▶ to start playback.
Pause playback	Press ▶▶ . Press again to resume.
Skip to the next recording/audio file	Press ▶▶ or ▶ .
Skip to the previous recording/audio file	Press ◀◀ or ◀ within the first 3 seconds of the current recording/file.

Listening to Weather Forecasts

Listen to today's local forecast	Press WEATHER once.
Listen to 3-day local forecast	Press WEATHER twice.

For information on new and upcoming products and to register your new radio, visit www.arinfiniteradio.com.

Audiovox Electronics Corp.
150 Marcus Blvd., Hauppauge, NY 11788
© 2009 Audiovox Electronics Corp.
Trademark Registered
www.audiovox.com

