**USER GUIDE** 





## **AURA SMART WATCH**

KAAURASWBTA



### **SAFETY & WARNINGS**

- Read the contents of this user guide carefully to ensure that you can use this product correctly and safely.
- Only use the strap provided with this product to prevent affecting the antenna signal of the watch, resulting in unclear calls and inability to locate and other problems.
- The watch should be charging 3 hours at least before use.

#### Maintenance

- Non-professionals are not allowed to disassemble the watch and other accessories by themselves. When the watch and accessories malfunction, contact help.Kogan.com for support
- Do not use chemical solvents or detergents to clean this product.
- Avoid dropping, knocking or vibrating the watch. Rough handling of the watch will
  cause the screen to break and damage the internal circuit board and precision
  structure.
- In case of abnormal phenomena during use, press and hold the power button until the watch is turned on.
- To prolong the service life of the battery, keep the battery fully charged. If the charged battery is left unused for a long time, the battery will gradually discharge by itself. When not in use, place the watch in a cool, dry and dark place after charging.
- When the strap is stained with sweat, dust, etc., wipe it with a clean with a dry soft cloth
- If the charging contacts are dirty, use a soft dry cloth to clean them and do not scratch them with hard metal objects.
- When the watch strap is old and cracked, it must be replaced with a new one.
- Before cleaning the watch, turn off the watch.
- Do not clean the watch while charging.
- Do not use heat such as a hair dryer to keep the watch dry.
- Do not use mechanical tools such as pressurised air guns and washing machines to clean the watch.

#### Charging and Battery

- Ensure the contacts are dry and free from dirt before charging.
- Do not throw the watch into fire, nor expose it to direct sunlight, fire or similar excessive heat to avoid battery leakage, overheating, bursting or fire.
- There is a danger of explosion if the battery is incorrectly replaced.
- During charging, the temperature of the battery will rise, do not place the watch together with flammable objects (such as: bedside, clothing, books, so as not to cause a fire.
- The battery of this product is built into the watch. It is strictly forbidden to disassemble, squeeze, heat or burn the battery. It is strictly forbidden to use sharp objects, screwdrivers, etc. to touch or pry the battery. The above operations may cause the battery to catch fire or burn.
- Do not use or store this product in environments with high temperature, high pressure, humidity, strong static electricity and strong magnetic fields.
- It is recommended to charge at a temperature above 5°C and below 35°C to avoid battery performance degradation.
- The battery of this product is built into the watch. It is strictly forbidden to disassemble, squeeze, heat or burn the battery. It is strictly forbidden to use sharp objects, screwdrivers, etc. to touch or pry the battery. The above operations may cause the battery to catch fire or burn.
- Do not use or store this product in environments with high temperature, high pressure, humidity, strong static electricity and strong magnetic fields.
- It is recommended to charge at a temperature above 5°C and below 35°C to avoid battery performance degradation.

#### Wearing the Watch

- When wearing the watch, adjust the tightness of the strap. It should not be too tight to
  allow the skin to breathe; it should not be too loose to prevent the watch from falling off
  or being damaged.
- Avoid wearing the watch in the shower, otherwise the watch may be damaged.
- If the sound becomes weaker after the watch is soaked in water, tap the water out of the speaker and the sound will return to normal.

#### Skin Allergies

- Some people are susceptible to allergies and may feel uncomfortable when using wearable devices. Pay special attention when wearing a watch.
- If you feel discomfort, it may be caused by wearing it too tight for too long. It is
  recommended that you adjust the tightness of the strap properly or wear it on the
  another hand.
- If the skin around or in contact with the watch becomes red, swollen, itchy or has other symptoms of discomfort, stop using it immediately and consult a doctor.
- If you need to replace the watch strap, contact help.Kogan.com for support.
- Discomfort may also be re-induced or increased if continued use after symptoms disappear.

#### Waterproof Performance

- This watch should not be used for bathing, swimming, diving, water skiing and highspeed water flow or submerged in shallow water.
- Water resistance is not a permanent condition and may decrease over time. To ensure proper use of your watch, follow these tips: Do not wear your watch while swimming, showering, sauna, sweating (or in a steam room) and parking in hot springs, etc.
- Avoid subjecting the watch to sudden temperature changes (such as blowing the watch with hot air from a hair dryer).
- Avoid contact with high-speed running water, such as faucets, rafting, surfing and water skiing.
- Avoid dropping or subjecting the watch to shocks, as the water resistance of the device may be impaired.
- Avoid contact with solvents (white wine, medical alcohol, etc.), acidic substances, detergents, soapy water, perfume, spray insecticide, lotion, sunscreen, oil, hair dye or bubble water, etc.
- Wipe off the product in time when sweat adheres to it for a long time.
- After the watch meets water (such as washing hands). it is necessary to drain the
  accumulated water in the speaker and microphone holes or use it after drying
  thoroughly to avoid affecting the sound.

#### Medical

• The measurement results of this product are for reference only and are not intended for any medical use or basis. Always follow the doctor's instructions

### **OPERATION**

#### Charging

Align the charging contacts of the watch with metallic contacts on the charging cable until charging power indicator appears on the watch screen. Note: The watch needs to be charged to activate it when it is started for the first time.



#### Note:

Do not use any other charger other than the one supplied with this watch.

#### Operating the Watch

- 1. Power on: When the watch is powered off, press and hold the function button for 5 seconds to turn it on. The home screen of the watch will be displayed after booting.
- Touch screen operation: From the home screen, swipe to the right to the menu screen, then tap the function icon to enter the corresponding sub-menu.
- 3. Wake up screen: When the watch screen is off, you can press the power button to wake up the screen. If the gesture control is enabled in the APP, you can also wake up the screen by turning your wrist.
- Shutdown: open the setting menu, click System → Shut down, click to shut down.




#### Removing the Strap

Remove the strap from the watch by sliding the quick release on the strap.



#### Shortcuts

- 1. Long press the screen to change the home page thumbnail. Swipe left and right to view the different options, then touch the screen to confirm.
- 2. Swipe to the right: Daily activity, Games, Alarms, Sports, etc. Swipe up and down to navigate the list and tap a function to select.
- 3. Swipe down: Battery, Bluetooth, Time and shortcut icons.
- 4. Swipe up: Storage information.
- 5. Swipe to the left: Daily activity, Heart rate, Sleep, Weather (additional functions can be added to this interface).



#### Settings Menu

You can change the appearance of the Menu. From menu Setting  $\rightarrow$  Choose style  $\rightarrow$  Four icon or List.







#### Clock Display

When in in clock mode, long press on the screen and select a different clock interfaces.



#### Screen Lock

In the APP select Personal centre → Device → Screen lock.

You can turn on the Screen lock after setting a password to prevent your children from overusing the watch. If the Screen lock is turned on, a password is required when using the watch.



## **APP INSTALLATION**

Download the Smart-Time Pro App

Download the "Hit Fit Pro" app from the iOS App Store or the Google Play store, or by scanning the QR code below.






For Android

For iOS

#### Pairing

- 1. Ensure Bluetooth and GPS is enabled on your phone.
- 2. Open "Hit fit Pro" App.
- 3. From the home screen, press Personal centre → Device menu to open the "Searching Devices" page.
- 4. Press "More" to search for the watch, select "Aura Smart Watch" to pair the watch as below.
  - Note: In the "Setting" menu on the watch press System  $\rightarrow$  System version to check the watch's Bluetooth name.
- 5. After pairing successfully, the "\int " icon will appear in the watch's status bar.

  Note: If you want your watch to receive third-party notifications, you need to turn on the notification permissions.







For iOS systems, when prompted, you will need to agree to pair allow iPhone notifications.

Note: During the pairing process, "Hit fit Pro" will prompt you to enable GPS and Bluetooth and authorise "Hit fit Pro" to get access to the GPS on your mobile phone.



#### Synchronising Data

Pair your watch with "Hit fit Pro" App, open App, in the home page screen, swipe down to synchronise data. Your data will be shown on App accordingly.



# FUNCTIONS

Activity	
Track daily calories, distance and steps.	
Games	
Play games on the watch. (Eat hot dogs, Jump, Racing car, Number Klots, Greedy Snake, Bubble Shooter Mania, 3-point Shooting).	
You can also download games through the "Hit Fit Pro" App.	
Alarm	
Add, customise and delete up to 5 alarms.	
Sports	
Track sports such as Walking, Running, Climbing, Riding, Basketball, Football, Baseball, Tennis, Rope skipping and Free sports.	<b>*</b>
Sports Record	
If you have done any sports and saved, in this function will show the information of sports record.	
Heart Rate	Heart rate 08:30
The watch will measure the user's heart rate under the heart rate measurement interface. After the test is completed, the vibration will display the result. After no operation, the screen will automatically go out.	86 Measuring
Date & Time	
You can set the time, set the date, choose the time display mode.	
Sleep	Sleep 08:30
<ul> <li>Function introduction: The watch will display the user's sleep time the night before. (Sleep measurement time 21:30 - 12:00 next day)</li> </ul>	08 H 30 M
Swipe the main interface left and right, click sleep to switch to the sleep interface, you can view the sleep time of the previous day.	01 H 25 M   07 H 05 M   DEEP 6 LIGHT

Weather After connected with APP, the watch	will show local weather information.	Weather 08:30  Sun 125 ~ 128*  Rain  Mon 125 ~ 128*  Thunderstorm  Tue 125 ~ 128*  Sunny
Blood Oxygen Place the watch on your wrist to mea value.		
Message		
When connected to Bluetooth, notific to your watch. (You need to open the		
Timer		
Switch to the timer interface, click to can start/pause/reset switching with		
Switch to the stopwatch interface, you can choose 1min, 5min, 10min or set any time you want to use countdown function. You can start/pause/reset switching with a single touch.		
Music Control the following functions of you Play/pause Next/previous track Increase/decrease volume		
Find phone When the watch is connected to the APP, the phone will make a sound after tapping it.		
Settings  Language  Choose style  Screen display  Do not disturb	<ul><li>Battery</li><li>Vibration</li><li>System</li></ul>	

## SPECIFICATIONS

CPU RTL8762D

ARM Cortex-M0 53MHz

Memory RAM 128KB + ROM 128Mb


Touch screen 1.69" IPS

240x280 big screen, 2.5D glass

Bluetooth version 5.0

Battery Lithium-ion 3.7V/260mAh

# NOTES



#### Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up.

For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to help.kogan.com

